



## NATURE WINTER

### TRIGGER AIR FRESHENER

- Long lasting deodorising effect
- More environmentally friendly due to water-based composition
- Balsamic wood scent (Balsamic amber wood)

Air freshener with long lasting intense, wintery scent that leaves a pleasant lingering fragrance.

### HOW TO USE

1. Press the safety button on the lower side of the dispenser neck to release the sprayer. 2. Press the dispenser right down at least 2/3 times to freshen the air (pressing for longer will make the scent more intense and long lasting).

### DILUTION

Ready to use.

### TECHNICAL DATA

**ASPECT:** Clear liquid  
**PERFUME:** Balsamic wood  
**COLOR:** Colorless  
**ACTIVE SUBSTANCE [%]:** 9,4 ± 0,9  
**PH:** 7,6 ± 0,5

### PICTOGRAMS

### WARNINGS

If medical advice is needed, have product container or label at hand. Keep out of reach of children. Contents BENZISOTHIAZOLINONE: May produce an allergic reaction.

### NOTES

Do not spray directly onto food and naked flames. Do not spray towards yourself or others. Store in a cool place away from sunlight. People who suffer from fragrance sensitivity should use this product with caution. For use on delicate fabrics, test on a small hidden part first. Air fresheners do not replace good hygiene practices. PRODUCT FOR PROFESSIONAL USE. SAFETY DATA SHEET AVAILABLE ON REQUEST FOR PROFESSIONAL USERS.

### PACKAGING

CODE	SIZE	QUANTITY	PALLET
5020	ml 350	12	20x3=60