



NATURE AUTUMN

TRIGGER AIR FRESHENER

- Long lasting deodorising effect
- More environmentally friendly due to water-based composition
- Fresh scent (Leaves fresh wind)

Water-based trigger air freshener with long lasting fresh, autumn scent that leaves a lingering fragrance and eliminates any unpleasant smells.

HOW TO USE

1. Press the safety button on the lower side of the dispenser neck to release the sprayer. 2. Press the dispenser right down at least 2/3 times to freshen the air (pressing for longer will make the scent more intense and long lasting).

DILUTION

Ready to use.

TECHNICAL DATA

ASPECT: Clear liquid
PERFUME: Sea breeze
COLOR: Colorless
ACTIVE SUBSTANCE [%]: $9,4 \pm 0,9$
PH: $7,6 \pm 0,5$
DENSITY: 0.997

PICTOGRAMS

WARNINGS

Contents BENZISOTHIAZOLINONE: May produce an allergic reaction.

NOTES

Do not spray directly onto food and naked flames. Do not spray towards yourself or others. Store in a cool place away from sunlight. People who suffer from fragrance sensitivity should use this product with caution. For use on delicate fabrics, test on a small hidden part first. Air fresheners do not replace good hygiene practices.

Only for professional use. Safety data sheet available on request.

PACKAGING

CODE	SIZE	QUANTITY	PALLET
5019	ml 350	12	20x3=60